

# PROFESSIONAL USER MANUAL

Images are representative of the Skeletime® Total Range



1. Backing Pad for sander, Totem Skeletime Pad
2. Standard assembly of Totem Skeletime Pad
3. Non-standard assembly of Totem Skeletime Pad
4. Skeletime Saver extends the life of the adhesive velcro, to be inserted between the Totem Pad N° 1 and the Skeletime Professional interfaces N° 5,6,7
5. Totem Skeletime Pad + Skeletime Strong Rigid(green) to be used to rectify the sanding on putty/filler or primer on flat surfaces
6. Totem Skeletime Pad + Skeletime Hard(red) to be used for sanding and rectify putty on curved surfaces
7. Totem Skeletime Pad + Skeletime Medium(blue) to be used to sand and rectify primer or paints on curved surfaces
8. Totem Skeletime Pad + Skeletime Rubber(white) to be used to sand plastic materials such as car bumpers or sanding works which do not require surface and rectify
9. Totem Skeletime Pad + Skeletime Foam(black) to be used to finish the sanding with a extra soft support when needed

Produced by SKEBA S.R.L. Buy on: [www.skeletime.info](http://www.skeletime.info) E-mail: [info@skeba-srl.it](mailto:info@skeba-srl.it)

# SKELETIME®

# PROFESSIONAL USER MANUAL

Before use, apply Skeletime Saver to the back of the patented Skeletime® interface (between the Skeletime interface and the backing pad) and press firmly to join the parts perfectly.

Set the use of the sander to no more than 6/7000 Rpm.

Skeletime patented interfaces must be in contact with the surface to be sanded before activating the sander.

Start the sander.

Press the sander only as necessary to maintain contact between the abrasive and the support to be worked.

Use the sander like a hand pad with large diagonal, vertical and horizontal movements and follow the profile of the surface to be sanded.

**SKELETIME®**